



5/10

## 8050-1-LR ASSEMBLY INSTRUCTIONS

- 1) Remove outside drawers (2) by depressing tabs on drawer slides & pulling drawers out.
- 1) Lay case top upside down on a soft fabric surface( so as not to scratch top surface ).
- 2) Attach each leg into each corner using the 40mm bolts (2 per leg). (do not tighten completely).
- 3) Attach the center base foot to the base frame using the 50mm bolts (2).
- 4) Attach the base frame & base corner feet to each corner leg using 90mm bolts (2 per foot) & tighten securely.
- 5) Now tighten each leg into the corner(s) of the desk.
- 6) Place the desk in an upright position. Insert the outer drawers.
- 7) Place desk in desired location in the upright position and level the case.